

## **Effective Stress Calculation in Undrained Materials**

RS2 offers an undrained effective stress analysis for soil layers in combination with effective strength parameters. RS2 uses the undrained effective stress analysis combined with effective strength parameters ( $\phi'$  and  $c'$ ) to obtain the undrained shear strength of a material. Pore pressure development is critical in identifying the correct effective stress path leading to a realistic failure value of undrained shear strength ( $c_u$  or  $s_u$ ).

### **1. Undrained Effective Stress Calculation**

When the undrained behaviour is selected for the material, special elements developed in RS2 will be automatically selected to account for the numerical stability when dealing with incompressible material.

Pore pressure in a soil body can usually be attributed to the presence of water and contributes to the total stress level within the soil. Terzaghi's principle states that total stresses ( $\sigma$ ) are divided into effective stresses ( $\sigma'$ ), pore pressure ( $p$ ), and pore water pressure ( $p_w$ ). Note that water does not sustain shear stress, therefore total shear stress is equal to effective shear stress.

$$\underline{\sigma} = \underline{\sigma'} + mp \quad (1.1a)$$

Where,

$$m = \begin{bmatrix} 1 \\ 1 \\ 1 \\ 0 \\ 0 \\ 0 \end{bmatrix} \text{ and } p = \alpha S_e p_w \quad (1.1b)$$

$$\sigma_{xx} = \sigma'_{xx} + \alpha S_e p_w \quad (1.1c)$$

$$\sigma_{yy} = \sigma'_{yy} + \alpha S_e p_w \quad (1.1d)$$

$$\sigma_{zz} = \sigma'_{zz} + \alpha S_e p_w \quad (1.1e)$$

$$\sigma_{xy} = \sigma'_{xy} \quad (1.1f)$$

$$\sigma_{yz} = \sigma'_{yz} \quad (1.1g)$$

$$\sigma_{zx} = \sigma'_{zx} \quad (1.1h)$$

Where  $\alpha$  = Biot's pore pressure coefficient and  $S_e$  = effective degree of saturation. Considering incompressible grains,  $\alpha = 1$ . Additional details about compressible grains

and compressible solid material ( $\alpha < 1$ ) are provided in the Biot's coefficient section below.

Pore pressure is the product  $\alpha S_e P_w$  and is termed  $p$  in RS2. The system of equations to be solved at each iteration for initial stiffness is:

$$\mathbf{K}_{eq} \Delta \mathbf{U}^i = \mathbf{R}^{i-1} \quad (1.2)$$

Where  $\mathbf{K}_{eq}$  is the stiffness matrix,  $\Delta \mathbf{U}^i$  is the change in displacement for the current iteration,  $\mathbf{R}^{i-1}$  is the residual force from the previous iteration, which is calculated as the difference between the external force and the internal force at the current iteration.

The stiffness matrix ( $\mathbf{K}_{eq}$ ) formulation is:

$$\mathbf{K}_{eq} = \mathbf{K}_{eff} + \mathbf{K}_u \quad (1.3a)$$

$$\mathbf{K}_{eff} = \int \mathbf{B}^T \mathbf{D}_e \mathbf{B} dV \quad (1.3b)$$

where  $\mathbf{D}_e$  is the elastic stress-strain matrix and  $\mathbf{B}$  is the strain-displacement matrix.

$$\mathbf{K}_u = \mathbf{Q} \mathbf{E}^T \mathbf{F} \mathbf{E} \bar{\mathbf{Q}}^T \quad (1.3c)$$

$$\mathbf{Q} = \int \mathbf{B}^T \alpha \chi m \mathbf{N}_p \quad (1.3d)$$

$$\mathbf{E} = \int \mathbf{B}_u^T \alpha S_w m \mathbf{N}_p \quad (1.3e)$$

$$\mathbf{B}_u = \mathbf{L} \mathbf{N}_u \quad (1.3f)$$

$$\mathbf{F} = \int \mathbf{N}_u^T \mathbf{K}_f \mathbf{N}_u \quad (1.3g)$$

$$\bar{\mathbf{Q}} = \int \mathbf{B}^T S_w \alpha m \mathbf{N}_p \quad (1.3h)$$

where  $S_w$  is the degree of saturation, and  $\chi$  is the coefficient.

If negative pore pressure cutoff and single effective was not selected:

$$\begin{cases} K_f = 0 \text{ for pore pressure} \leq 0 \\ K_f = \frac{1}{(\alpha - n)K_s + \frac{n}{K_w}} \text{ for pore pressure} > 0 \end{cases} \quad (1.4)$$

If single effective parameters are activated:

$$\left\{ \begin{array}{l} K_f = \frac{1}{(\alpha - n)K_s + \frac{n}{K_w}} \text{ for pore pressure } \geq 0 \\ K_f = \frac{1}{\frac{(\alpha - n)}{K_s} S_w \left( S_w + \frac{C_s}{n} p \right) + \frac{n S_w}{K_w} + C_s} \text{ for pore pressure } < 0 \end{array} \right. \quad (1.5)$$

Where  $K_s$  is the bulk modulus of the solid material,  $K_w = 2 * 10^6 \text{ kN/m}^2$ ,  $C_s$  is the compressibility of the solid material,  $p$  is the pore pressure, and  $n$  is the porosity of the soil.

## 2. Skempton B-Parameter

When using undrained drainage conditions, the following equations are used to differentiate between total stress rates, effective stress rates, and rates of excess pore pressure:

$$\text{Total stress: } \delta\sigma_m = (K_f + K')\delta\varepsilon_v \quad (2.1a)$$

$$\text{Excess pore pressure: } \delta p_{\text{excess}} = K_f \delta\varepsilon_v \quad (2.1b)$$

$$\text{Effective stress: } \delta\sigma'_m = K' \delta\varepsilon_v \quad (2.1c)$$

The value of Skempton's B-parameter is calculated using the ratio of the bulk stiffnesses of the soil skeleton and the pore fluid:

$$B = \frac{\alpha}{\alpha + n\left(\frac{K'}{K_w} + \alpha - 1\right)}$$

Where  $K'$  is the effective bulk modulus for the soil matrix and  $K_w = 2 * 10^6 \text{ kN/m}^2$ .

The special undrained behaviour option in RS2 requires calculations that using effective stiffness parameters, with a distinction between effective stresses and excess pore pressures. The calculations may not completely address shear induced effective pore pressures.

This analysis requires effective soil parameters and is therefore very useful when these parameters are available. However, with soft soil projects, accurate effective soil parameter data may not be accessible. Therefore, in situ and laboratory tests may

be performed to obtain undrained soil parameter data. In these cases, Hooke's law can be used to convert measured values of undrained Young's moduli into effective Young's moduli:

$$E' = \frac{2(1 + \nu')}{3} E_u \quad (2.3)$$

This direct conversion from measured to effective values is not possible for advanced models. In these advanced cases, it is suggested to estimate the effective stress parameter from the measured parameter, then perform an undrained test to verify the resulting undrained stiffness (and adapt the estimated effective stiffness value if needed). The *Soil* test facility (Reference Manual) may be used in these circumstances.

### 3. Biot Pore Pressure Coefficient, $\alpha$

Generally, the compressibility of the soil skeleton will be greater than that of the individual grains of soil in a mass; therefore, deformations of individual soil grains can be disregarded. In cases with deep soil layers at high pressures, the stiffness of the soil/rock matrix will approach that of the material of the soil/rock grains; in these cases, the compressibility of the solid material must be considered. This affects the division of total stress into effective stress and pore pressure. In cases with compressible solid material, Terzaghi's effective stress can be defined using the following equation:

$$\underline{\sigma}' = \underline{\sigma} - \alpha S_e \underline{m} p_w \quad (3.1)$$

Where  $\alpha$  is Biot's pore pressure coefficient,  $S_e$  is the effective degree of saturation,  $\underline{m}$  is a vector (with unity values for normal components and 0-values for shear components), and  $p_w$  is the pore water pressure. The following equation shows the definition of Biot's pore pressure coefficient:

$$\alpha = 1 - \frac{K'}{K_s} \quad (3.2)$$

Where  $K'$  is the effective bulk modulus for the soil matrix and  $K_s$  is the bulk modulus of the solid material. Note that for an incompressible solid material ( $K_s = \infty$ ), Terzaghi's original stress definition holds true. Lower values of  $\alpha$  indicate that for given values of total stress and pore water pressure, the resulting effective stress is higher than that of an incompressible solid material ( $\alpha = 1$ ).

The value of Biot's pore pressure coefficient is automatically calculated by RS2, but the value may be changed manually by the user.